





HOW TO IMPORT PAN-FILES INTO PV-SYST



1. Select the import function



2. Open the downloaded ZIP file



Legend:


External project/component is already imported in local user database

(*) External project/component is different than the one in local user database

Component overrides one from PVsyst's default database

3. Select required modules and press „Import“

Press and hold Ctrl to select multiple modules



Now you can use our SOLARWATT modules in your simulation.