

# **SOLARWATT FACADE SYSTEM**

#### **PLANNING SUPPORT**

VERSION: 08/2014




SOLARWATT Facade System Planning Support | SOLARWATT GmbH |

## **SOLARWATT FACADE SYSTEM**

Postcode, City	Environmental specifics
Building dimensions	Wind load(ifavailable)
Length x Width x Height	kN/m²
Wall construction	
Material (brick, concrete, wooden stand, etc.)	
Heat insulation (yes/no)	
If yes:	
Insulation thickness	Insulation material
Plaster thickness in mm	
Module field	
Length x Width [m]	bottom/top/side [m]


We need some information on the project in order to deliver a system that has been adapted to your specific circumstances



The horizontal and vertical distance between the modules is 10 mm.

The heat insulation surface should be resistant to driving rain. The system's good ventilation ensures that any moisture will dry quickly.

Ill. Four-point mounting bracket; wind load ≤ 0.9 kN, suction load up to 0.9 kN/m2



Six-point mounting bracket; wind load ≤ 1.5 kN, suction load up to 1.5 kN/m2

SOLARWATT Facade System Planning Support | SOLARWATT GmbH |

## **VERTICAL PROFILE**

#### Ill. Vertical profile positioning

A standard façade segment consists of five mod-

Two or three vertical profiles per module row are installed for both solutions, depending on the wind loads the building is exposed to. The illustrations show how the profiles are positioned.


# Ill. Longitudinal section with location of brackets for locating and non-locating bearing


A standard segment is comprised of 3006 mmlong profiles, which are secured to the wall using mounting brackets.

The longitudinal section shows where the mounting points are located.


While non-locating bearings only absorb wind loads (horizontal loads), the locating bearings bear the weight of the equipment (vertical loads). The construction foundation must therefore be capable of continually absorbing 800N of vertical load per locating bearing. Each locating bearing consists of at least two independent mounting points.

Dividing the load between locating and non-locating bearings allows free thermal expansion of the individual segments, and prevents thermal strain from developing in the system.






### **MODULE FIELD TERMINATION**



Ill. Detail, module field upper end




Ill. Detail, module field lower end

SOLARWATT Facade System Planning Support | SOLARWATT GmbH |

Ill. Montage principle

## MONTAGE PRINCIPLE

## MONTAGE PRINCIPLE



Ill. Module attachment - top

Ill: Module attachment - middle


#### **⚠** NOTE


The necessary means for attaching the system to the foundation depend on the materials in use, and are not included!


Recommended materials for anchoring into concrete:

Hilti HST-R M10 (concrete at least C20/25) or Hilti HIT-HY 200-A + HIT-V-R M10 (concrete at least C12/15)

Any other approved fasteners having equal or better ratings may also be used.







Ill: Module attachment - middle patented click system



Interested in our products and services? We'd be glad to assist you. Just call us!

#### SOLARWATT GmbH

Maria-Reiche-Str. 2a 01109 Dresden, Germany Tel. +49 351 8895-0 Fax +49 351 8895-111 info@solarwatt.de www.solarwatt.de