




## Wichtiger Anschluss Hinweis!



### Batterieanschluss


Bei dem Kommunikationsanschluss der Batterie über den RJ45 Stecker ist darauf zu achten das dieser **nur** in die RJ 45 Buchse des „BAT“ Anschlusses eingesteckt werden darf.



Bei einem Anschluss auf den Buchsen „Lan“ oder „Switch“ kann es zu einer Beschädigung des Geräts kommen. Bei fehlerhaftem Anschluss handelt sich um einen unsachgemäßen Gebrauch, welcher von der Garantie ausgeschlossen ist!

### Zähleranschluss


An der Buchse „Switch“ dürfen **nur** freigegebene Energiezähler oder der hy-switch angeschlossen werden.



## ! Important connection note! !

### Battery connection

When connecting the battery for communication via the RJ45 plug, make sure that it is plugged into the RJ45 socket of the 'BAT' connection.



Connecting to the 'Lan' or 'Switch' sockets may damage the device.  
Incorrect connection constitutes improper use, which is excluded from the warranty!

---

### Connection from energy meter

**Only** authorized energy meters or the hy-switch is allowed to be connected at the 'Switch' socket.

